

USER MANUAL

FOXMAN-UN

Teleprotection Application UI

Document ID	1MRC000133-FR1800
Document edition	FOXMAN-UN System Release: R18
	Revision: A
	Date: 2025-10-15

Copyright and confidentiality

Copyright in this document vests in Hitachi Energy.

Manuals and software are protected by copyright. All rights reserved. The copying, reproduction, translation, conversion into any electronic medium or machine scannable form is not permitted, either in whole or in part. The contents of the manual may not be disclosed by the recipient to any third party, without the prior written agreement of Hitachi Energy. An exception is the preparation of a backup copy of the software for your own use. For devices with embedded software, the end-user license agreement provided with the software applies.

This document may not be used for any purposes except those specifically authorized by contract or otherwise in writing by Hitachi Energy.

Disclaimer

This document contains information about one or more Hitachi Energy products and may include a description of or a reference to one or more standards that may be generally relevant to the Hitachi Energy products. The presence of any such description of a standard or reference to a standard is not a representation that all the Hitachi Energy products referenced in this document support all the features of the described or referenced standard. In order to determine the specific features supported by a particular Hitachi Energy product, the reader should consult the product specifications for that Hitachi Energy product. In no event shall Hitachi Energy be liable for direct, indirect, special, incidental, or consequential damages of any nature or kind arising from the use of this document, nor shall Hitachi Energy be liable for incidental or consequential damages arising from the use of any software or hardware described in this document.

Hitachi Energy may have one or more patents or pending patent applications protecting the intellectual property in the Hitachi Energy products described in this document. The information in this document is subject to change without notice and should not be construed as a commitment by Hitachi Energy. Hitachi Energy assumes no responsibility for any errors that may appear in this document.

All people responsible for applying the equipment addressed in this manual must satisfy themselves that each intended application is suitable and acceptable, including compliance with any applicable safety or other operational requirements. Any risks in applications where a system failure and/or product failure would create a risk for harm to property or persons (including but not limited to personal injuries or death) shall be the sole responsibility of the person or entity applying the equipment, and those so responsible are hereby requested to ensure that all measures are taken to exclude or mitigate such risks.

Products described or referenced in this document are designed to be connected and to communicate information and data through network interfaces, which should be connected to a secure network. It is the sole responsibility of the system/product owner to provide and continuously ensure a secure connection between the product and the system network and/or any other networks that may be connected.

The system/product owners must establish and maintain appropriate measures, including, but not limited to, the installation of firewalls, application of authentication measures, encryption of data, installation of antivirus programs, and so on, to protect these products, the network, its system, and interfaces against security breaches, unauthorized access, interference, intrusion, leakage, and/or theft of data or information.

Hitachi Energy performs functionality testing on released products and updates. However, system/product owners are ultimately responsible for ensuring that any product updates or other major system updates (to include but not limited to code changes, configuration file changes, third-party software updates or patches, hardware change out, and so on) are compatible with the security measures implemented. The system/product owners must verify that the system and associated products function as expected in the environment in which they are deployed. Hitachi Energy and its affiliates are not liable for damages and/or losses related to security breaches, any unauthorized access, interference, intrusion, leakage, and/or theft of data or information.

This document and parts thereof must not be reproduced or copied without written permission from Hitachi Energy, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

Contents

1	Introduction	4
1.1	General	4
2	UI Overview	5
3	Feature Description	6
3.1	System Operation	6
3.2	Main GUI	6
3.3	Teleprotection Service Provisioning	7
3.3.1	Prerequisites	7
3.3.2	Starting the “Create Teleprotection Service” Wizard	7
3.4	Teleprotection Service Information	13
3.5	Teleprotection Service Removal	14
3.6	VPWS (Virtual Private Wire Services) Details	15
3.7	Section Details	16
3.8	NE (Network Elements) Details	17
3.9	Creating end-to-end Circuit	18
4	Annex	21
4.1	Associated Documents	21
4.2	Document History	21

1 Introduction

1.1 General

This document provides a description of the Teleprotection application in FOXMAN-UN. The Teleprotection application is part of the E2E (end-to-end) Services & Applications in the FOXMAN-UN Web UI.

2 UI Overview

For an overview of the Web UI refer to [\[1MRC000084\] User Manual “Web UI”](#).


3 Feature Description

This section covers the following subjects:

- [System Operation](#),
- [Main GUI](#),
- [Teleprotection Service Provisioning](#), [Teleprotection Service Removal](#),
- [VPWS \(Virtual Private Wire Services\) Details](#),
- [NE \(Network Elements\) Details](#),
- [Section Details](#).

3.1 System Operation

The Teleprotection application UI can be started from the following menu:
NEM Desktop > Application > Teleprotection...



The Teleprotection application can also be called from the Homepage via the “Teleprotection” tile:



3.2 Main GUI

The user interface provides the following five main tabs:



Circuit Service, see

- [Creating end-to-end Circuit](#).



Teleprotection Service, see

- [Teleprotection Service Provisioning](#),
- [Teleprotection Service Removal](#).



VPWS, see [VPWS \(Virtual Private Wire Services\) Details](#).



Section, see [Section Details](#).



NE, see [NE \(Network Elements\) Details](#).

3.3 Teleprotection Service Provisioning

3.3.1 Prerequisites

To create and deploy a Teleprotection service, both NEs which are meant to be the service end-points (Initiator NE, Terminator NE) need to:


- be manageable;
- be present in NP and ENP domains;
- have at least one Teleprotection unit which is assigned and still has capability in terms of:
 - supporting the required type of teleprotection,
 - number of interfaces,
 - number of Pseudowires;
- be operating in required Termination Mode;
- provide the required interface configuration type (e.g., IEEE C37.94).

Transport Service requirements:


- VPWS Service Profile exists which meets Teleprotection service bandwidth requirements or has flexible bandwidth.
- The VPWS Service Profile must have fixed (i.e., NOT variable) tunnel protection settings; otherwise it cannot be selected during Teleprotection service creation.
- For Hitless services, only Service Profiles with unprotected tunnel are selectable (“protection=false”).
- For 1:1 services, only Service Profiles with protected tunnel are selectable (“protection=true”). 1:1 protection mode is not recommended for teleprotection services.
- Link path between Initiator NE and Terminator NE exists and meets bandwidth requirements considering Service Profile Class Type allocation.

3.3.2 Starting the “Create Teleprotection Service” Wizard

- Navigate to the Teleprotection Services tab:



- Use the “+ Create” action button:




- The “Create Teleprotection” wizard dialog window appears in front of the Teleprotection Service table and/or map.
- Follow the steps in the “Create Teleprotection” wizard (**bold** parameters are mandatory and require user input).

The Teleprotection service wizard guides you through service creation in 7 main steps as shown in the following sample.

Step 1 General

In step 1 “General” you need to provide basic service identification including


- **Name**
- Description (optional)
- **Teleprotection Type** (Differential; Distance; GOOSE/SV)
- **Protection Mode** (None; 1:1 (not recommended); Hitless)



Teleprotection Type and related Protection Modes have some dependencies and will also restrict their applicability to certain NEs and the units in operation on these NEs. Also see step 2.

Click “Next >” to proceed to step 2 “Endpoints”.

Step 2 Endpoints



Select an Initiator NE and a Terminator NE. If no suitable NEs are available due to their provisioning with appropriate units supporting the chosen teleprotection type and/or protection mode, you can click on “Show All” at the bottom of the selection list to include NEs that would provide teleprotection service features, but do not support the required combination of teleprotection type

and protection mode. Initiator and Terminator NE and the service connection are marked on the map.

If suitable NEs are selected, select the unit ports you want to use for the service. Use the “Show All” option for each NE to include units/ports that provide support for teleprotection services but are not available for selection, e.g., because they are already carrying such a service.


Once unit ports are selected, a proposed port configuration is added for both NEs with their pre-selected termination modes. If required, you can select a different termination mode from the drop-down list.

Click “Next >” to proceed to step 3 “Addressing”.

Step 3 Addressing

Step 3 proposes preselected settings for

- L2 addressing, transport 1;
- L2 addressing, transport 2;
- L3 addressing.




You can expand each of the characteristics to view the details and modify them if required. Note that some of the settings (e.g., L3 source IP addresses), if modified, need further actions to ensure a working service.

Click “Next >” to proceed to step 4 “Quality of Service & Timing”.

Step 4 Quality of Service & Timing


Depending on the service type, select the required settings for

- Guard Interval
- Measurement Interval
- Max Allowed Delay
- Excessive Packet Loss Error Threshold



or select the required settings for

- Frames Per Packet
- E2E Transmission Delay
- E2E Transmission Delay Threshold
- Sync Supervision:
 - GMs Locked by GPS
 - GMs Locked by GPS Or GM IDs Match
 - GMs Locked by GPS And GM IDs Match
 - GM IDs Match
 - None (Sync Supervision Disabled)




or accept the proposed QoS and timing settings. The required bandwidth is automatically calculated and displayed.

Click “Next >” to proceed to step 5 “Transport”.

Step 5 Transport


Select the appropriate service profile from the list of available service profiles. Click “Show All” to include service profiles in the list that are unsuitable for the selected service characteristics.



Once a suitable service profile is selected, the Class Type color, protection support, bandwidth, appropriate VPWS 1 and VPWS 2 and the AC (attachment circuit) are proposed if available.

The bandwidth can be modified if required.

The attachment circuit (AC) ports can be edited if required. Their port type is shown when expanding the port name using the expand arrow. Port changes need to be deployed and will take effect immediately, i.e. before service deployment.



If none are available they need to be created before proceeding.

Click “Next >” to proceed to step 6 “Tunnel”.

Step 6 Tunnel


If appropriate tunnels already exist, their names are proposed as “Tunnel 1” and “Tunnel 2”. The tunnels also appear on the map.

In case of disabling the “Force Distinct Path” option, only one tunnel is proposed.

If no appropriate tunnels exist, a new tunnel must be created for each path before proceeding. New tunnels can be routed manually or automatically.

If a selected tunnel needs to be modified before applying it for the service, click on the pen icon right to the tunnel name and make the necessary changes. The “info” icon right to the tunnel name shows detailed information about the selected tunnel.


If protection shall be applied, make sure to define a tunnel for both Working and Protecting path.



Click “Next >” to proceed to step 7 “Summary”.

Step 7 Summary

The summary will show the main service characteristics specified in the different steps. Details can be shown by expanding the individual step sections.



Click “Deploy” to deploy the service to the network.

Once deployed successfully, click “Finish” to close the wizard.


- The new service will now be listed in the Teleprotection Service table and, upon selection in the list, will be highlighted in the map.

3.4 Teleprotection Service Information


An existing Teleprotection service, when selected from the table or in the map, provides Summary information in the right panel, such as

- Admin State
- Issues, with the number of issues per severity (Critical, Major, Minor and Warning)
- Status information about Transport entities and tunnel entities
- General information, such as
 - Name,
 - Initiator,
 - Terminator,
 - Protection Mode.


Further details are provided in the right panel either from the drop-down field with



- Summary (see above),
- Configuration,
- Supervision,
- Health Monitors,
- Related, with
 - Summary (shows the number of involved sections, NEs, units, and ports),
 - Using (shows the number of involved VPWS, PWs, tunnels, service profiles, class types, sections, NEs, and ports; each of which can be further expanded for more detailed information and collapsed again to get back to the overview),
 - Used by (shows the number of circuit services; can be further expanded for more detailed information and collapsed again to get back to the overview).

For a complete overview on the selected service, click the “Details” button  in the ribbon.

This will open the details page with a structured view of all service details.



The details page can be closed by clicking on the close () icon in the upper right corner. This will return you to the Teleprotection app.

For a single selected Teleprotection from the entity browser, via the context menu, you can also

- Pin the selected service to add it to the icon bar of the details panel.
- Open the Initiator or Terminator NE in the local craft terminal (FOXCST) with the required user class, or open the Initiator or Terminator alarm list.
- Modify the service.
- Delete the service.
- Change the service admin state.
- Refresh the key (if transmitted over an encrypted tunnel).
- Enable, disable, resume or pause service supervision.

For multiple selected items from the left-hand list, via the context menu, you can also

- Delete the services.
- Change the services admin state.
- Refresh the key (if transmitted over an encrypted tunnel).
- Enable, disable, resume or pause service supervision.


3.5 Teleprotection Service Removal

Any created Teleprotection Service can be removed. Proceed as follows:

- Navigate to the Teleprotection Services tab:



- Select service to be removed in the table. It will be highlighted in the map. Optionally many services can be removed at once. To do that select several Teleprotection services in the table.
- Use the action menu with the three dots symbol - or the context menu - and trigger the Delete action:



- Confirm the service deletion, or cancel. Optionally you can choose whether or not to also delete the underlying transport service(s), i.e. the VPWS being used by the service(s).
- If confirmed, this will delete the service from the table and from the network. By default, transport service(s) will be removed.
- Expected result:
 A success message should be visible in the right bottom corner of the application view.
 After some processing time the removed services should no more be visible in the Teleprotection Services table and in the map.

3.6 VPWS (Virtual Private Wire Services) Details



All VPWS that are used for Teleprotection services are listed in this view.

You can select one or several items in the list. For a single selected item, you can view detailed information by expanding the right-hand details bar. The detailed information for a selected VPWS includes

Top information:

- Deployed state | Operational state
- Item name
- Item type (=VPWS)

Summary

- Config Status,
- Admin State,
- Issues, with the number of issues per severity (Critical, Major, Minor and Warning),
- Tunnel status,

General

- VPWS name (with hyperlink to the details page),
- Description,

- Bandwidth,
- Initiator,
- Terminator,
- Class Type,
- Service Profile,
- Status of deployment,
- Tunnel name (with hyperlink to the details page).

For a single selected item from the left-hand list, via the context menu, you can also

- Pin the selected VPWS to add it to the icon bar of the details panel.
- Open Legacy Details (this will open the legacy ENP dialog window and the service details window for the selected VPWS).
- Modify the VPWS.
- Align the VPWS if required.
- Synchronize the VPWS service or refresh the PW oper state.
- Open the Initiator or Terminator NE in the local craft terminal (FOXCST) with the required user class, or open the Initiator or Terminator alarm list.
- Change the VPWS admin state.
- Enable, disable, resume or pause service supervision.

For multiple selected items from the left-hand list, via the context menu, you can also

- Align the VPWS if required.
- Synchronize the VPWS service.
- Change the VPWS admin state.
- Enable, disable, resume or pause service supervision.

3.7 Section Details



All sections that are member of the NP (TDM) and/or ENP (MPLS) domains are listed in this view.

You can select one or several items in the list. For a single selected item, you can view detailed information by expanding the right-hand icon bar. The detailed information for a selected section includes

Top information:

- Deployed state | Operational state
- Item name
- Item type (=Network Section and physical layer type)

Summary

- Admin State,
- Highest Alarm Severity,
- Performance State.

Issues (with total number)

- Issues, with the number of issues per severity (Critical, Major, Minor and Warning),
- Initiator status, Terminator status.

General

- Section name,
- Initiator (with hyperlink to the details page),
- Terminator (with hyperlink to the details page),

- Type (physical port),
- Layer Rate,
- Bandwidth.

For a single selected item from the left-hand list, via the context menu, you can also

- Pin the selected section to add it to the icon bar of the details panel.
- Open Legacy Details (this will open the legacy ENP dialog window and the service details window for the selected section).
- Open the Initiator or Terminator NE in the local craft terminal (FOXCST) with the required user class, or open the Initiator or Terminator alarm list.
- Synchronize the MPLS link, reset the MPLS link bandwidth, or enable or disable the “use for routing” option.
- Enable, disable, resume or pause service supervision.

For multiple selected items from the left-hand list, via the context menu, you can also

- Enable, disable, resume or pause service supervision.

3.8 NE (Network Elements) Details



All Network Elements that are member of the NP (TDM) and/or ENP (MPLS) domains and have the capability to support Teleprotection services are listed in this view.

You can select one or several items in the list. For a single selected item, you can view detailed information by expanding the right-hand icon bar. The detailed information for a selected NE includes

Top information:

- Operational state | Supervision state
- Item name
- Item type (=Network Element), Number of Domains

Summary

- Highest Alarm Severity,
- Performance State.

Issues (with total number)

- Issues, with the number of issues per severity (Critical, Major, Minor and Warning),

General

- NE name (with hyperlink to the details page),
- Operational State,
- Supervision State,
- Highest Alarm Severity,
- Highest Alarm Severity (not acknowledged),
- Force Poll status,
- Last Force Poll Duration,
- Last Force Poll OK date and time,
- Last Force Poll Fail date and time.

For a single selected item from the left-hand list, via the context menu, you can also

- Pin the selected NE to add it to the icon bar of the details panel.
- Create
 - Teleprotection service starting on the selected NE.
 - Circuit service starting on the selected NE.

- Open the NE in the local craft terminal (FOXCAST) with the required user class.
- Synchronize the MPLS objects handled by the NE.
- Execute a Force Poll.
- Open the NE alarm list in Web UI.
- Open the NE alarm list (Legacy)

For multiple selected items from the left-hand list, no context menu selection is available.

3.9 Creating end-to-end Circuit




To create an end-to-end TDM service using one of the previously created Teleprotecton services, a specific Circuit Service creation wizard is available.

Once you have an appropriate Teleprotecton service configured (and deployed), click on the “+ Create” button in the ribbon of the “Circuit Service” tab. This will start the Circuit Service creation wizard.


Follow the steps in the wizard:

1 General




- Enter a service name.
 - Select the required layer Rate (P0_nc, P12)
- click “Next >” to proceed.

2 Endpoints




- Select the Initiator and Terminator NEs.
 - Select a port from the list of suitable ports for Initiator and Terminator NEs.
 Note that only ports with matching termination mode can be selected. If enable “Show All”, ports include such with any termination mode are shown for information purposes only.
 - Scroll down and select the suitable channel(s) from the list of channels for Initiator and Terminator NEs.
- click “Next >” to proceed.

3 Teleprotection Service




- From the list of available services, select the required service. Note that only services with a checkmark in the “Available” column can be selected.
- click “Next >” to proceed.

4 Summary



- Under “Endpoints” and under “Transport Services” you can verify the settings; once these are OK,
- click “Deploy” to deploy the circuit service configuration to the network.
- This will show a deployment status while the button in the lower right corner will display “Deploying...”



- Once successfully completed, the final deployment status is shown and the wizard can be closed with the “Finish” button.
- In case an error during deployment occurs, the errors are shown here.

4 Annex

4.1 Associated Documents

[1KHW002499] Release Note “FOXMAN-UN”

[1MRC000084] User Manual “Web UI”

4.2 Document History

Table 1: Document History

Document ID	FOXMAN-UN Release	Rev	Date	Changes since previous version
1MRC000133	R18	A	Sep 2025	Reworked and updated version for R18, including: - update of screenshots and descriptions for CES creation wizard, - update of screenshots and descriptions for Circuit creation wizard.

Hitachi Energy Ltd
Bruggerstrasse 72
5400 Baden - Switzerland

Phone: please refer to <https://www.hitachienergy.com/contact-us/Customer-Connect-Center>
(Customer Connect Center)

Email: communication.networks@hitachienergy.com

www.hitachienergy.com/communication-networks